

# Operating the Marantz PMD660

## Prepare and test the setup before your guest arrives

Plug microphone into “L MIC IN” socket on the back of the unit.

On the side of the microphone there is an On/Off switch. Ensure this is “On”.


Switch the Marantz power button to “On”. [Right side of the unit].



Press “REC PAUSE” [5] button and set your level by speaking into the mic and adjusting the “REC LEVEL” dial until the loudest level is peaking just below 0db on the level meters.



To prevent feedback, which will ruin your recording, turn your speaker volume right down. HP/SPK VOL [Left side of the unit].



Press “REC” [1] to start your recording and “STOP” [2] when finished.

Press “REC” again to start recording a new track.

To listen back, first turn your speaker volume back up.

Now, use “TRACK JUMP” [3] to go back through the tracks and “PLAY/PAUSE” [4] to play the track.

When all tracks are recorded, turn unit off.

